


感谢您购买我们公司的产品! 欲知更多产品信息, 请浏览以下官方网站: www.flysky-cn.com。如果您在使用中遇到任何问题, 请先查阅发射机帮助菜单或使用说明书。如果问题仍未得到解决, 请直接联系当地经销商或者访问如下网站联系客服人员: www.flysky-cn.com/service.asp

Quick Start Guide 快速操作指南


FS-I8



Copyright ©2013-2017 Flysky RC model technology co., td

注意事项

- 开始操作前请务必阅读以下安全信息!
- 请不要在夜晚或雷雨天气使用本产品, 恶劣的天气环境可能导致遥控设备失灵。
- 请不要在能见度有限的情况下使用本产品。
- 请不要在雨雪或有水的地方使用本产品。如果有液体进入到系统内部, 可能会导致运行不稳定或设备失灵。
- 信号干扰可能导致设备失控。为保证您和他人的安全, 请不要在以下地点使用本产品:
 - 基站附近或其他无线电话活跃的地方
 - 人多的地方或道路附近
 - 有客船的水域
 - 高压电线或通信广播天线附近
- 当你感到疲倦、不舒服, 或在摄入酒精或服食导致麻醉或兴奋的药物后, 不要操作本产品, 否则可能对自己或他人造成严重的伤害。
- 2.4GHz 无线电波段完全不同于之前所使用的低频无线电波段。使用时请确保模型产品在您的视线范围内飞行, 大的障碍物将阻断无线电频率信号从而导致遥控失灵型失控。
- 在使用过程中, 严禁紧握发射机天线, 否则将会大大减弱无线电传播信号的质量和强度, 导致遥控失灵。
- 在操作或使用模型后, 请勿触摸任何可能发热的部位, 如发动机、电机、定速设定等。这些部件可能非常热, 容易造成严重的烧伤。
- 遥控设备使用不当可能导致操作者或他人严重受伤, 甚至死亡。为保证您和设备的安全, 请仔细阅读使用说明书并按照要求进行操作。
- 使用前必须确保本产品与模型安装正确, 否则可能导致模型发生严重损坏。
- 关闭时, 请务必先关闭接收机电源, 然后关闭发射机。如果关闭发射机电源时接收机仍然在工作, 将有可能导致遥控设备失控或者引擎继续工作而引发事故。
- 操控时, 请先确认模型所有舵机的动作方向与操控方向一致。如果不一致, 请调整好正确的方向。
- 当遥控距离持续较远时, 有发生失控的可能。请适当缩短遥控的距离。
- 仅使用厂家指定的电池。
- 请勿打开、拆卸或自行维修电池。
- 请勿挤压、刺穿电池或接触电池的金属部件。
- 请勿将电池置于高温环境或液体中。
- 请注意防止电池跌落、碰撞或振动。
- 请将电池存放在干燥阴凉的环境中。
- 如果电池损坏, 请立即停止使用。






发射机概览

前视图:



后视图:



关机

- 断开接收机电源。接收机连接电源的情况下系统无法关机。
- 同时按下发射机的两个电源按键, 状态指示灯熄灭后表示发射机电源关闭。

关闭时, 请务必先断开接收机电源, 然后关闭发射机。如果关闭发射机电源时接收机仍然在工作, 将有可能导致遥控设备失控或者引擎继续工作而引发事故。

规格参数

通道个数	8
适合机型	固定翼 / 滑翔机 / 直升机
频率范围	2.408-2.475GHz 不高于 20 dBm
发射机功率	135
逻辑功能开启	500kHz
调制方式	第二代增强型自动跳频数字系统 (含第二代系统和第一代系统)
摇杆分辨率	GFSK
低电压报警	4096 级
数据输出	低于 3.7V 时
充电接口	Micro-USB PPM
天线长度	有 (USB)
机身重量	26mm(双天线)
输入电源	720g
显示方式	WQGA 3.55 寸 TFT 彩屏 262K240*400 点阵 LCD 白色背光电阻式触摸屏
帮助	190*95*255mm
功能菜单	有
外形颜色	黑色
认证	CE0678, FCC ID:N4ZFLYSKYI8



Thank you for purchasing our product! To find out more about our products, visit our website at www.flsky-cn.com. If you encounter any problem during use, refer to the transmitter's on-board help files or instruction manual first. If the problem persists, contact your local dealer or visit our service and support website for help: www.flsky-cn.com/service.asp.



Digital Proportional Radio Control System

CE0678 FCC ID:N4ZFLYSKYI8

[Http://www.flsky-cn.com](http://www.flsky-cn.com)

Copyright © 2013-2017 Flysky RC model technology co., Ltd

Edition: V2.1




Release date: 2016-5-24



Precautions

Read the safety messages listed below before operation!


- Do not use the product at night or during bad weather conditions, like rain or thunderstorms. It can cause erratic operation or loss of control.
- Do not use the product when visibility is limited.
- Do not use the product on rain or snow. Any exposure to moisture (water or snow) may cause erratic operation or loss of control.
- Interference may cause loss of control. To ensure the safety of you and others, do not operate in the following places:




- Do not use this product when you are tired, uncomfortable, or under the influence of alcohol or drugs. Doing so may cause serious injury to yourself or others.
- The 2.4GHz radio band is limited to line of sight. Always keep your model in sight as a large object can block the RF signal and lead to loss of control.
- Never grip the transmitter antenna during operation. It significantly degrades signal quality and strength and may cause loss of control.
- Do not touch any part of the model that may generate heat during operation, or immediately after use. The engine, motor or speed control, may be very hot and can cause serious burns.
- Misuse of this product may lead to serious injury or death. To ensure the safety of you and your equipment, read this manual and follow the instructions.
- Make sure the product is properly installed in your model. Failure to do so may result in serious injury.
- Make sure to disconnect the receiver battery before turning off the transmitter. Failure to do so may lead to unintended operation and cause an accident.
- Ensure that all motors operate in the correct direction. If not, adjust the direction first.
- Make sure the model flies within a certain distance. Otherwise, it would cause loss of control.
- Only use specified battery.
- Do not open, disassemble, or attempt to repair the battery.
- Do not crush/puncture the battery, or short the external contacts.
- Do not expose to excessive heat or liquids.
- Do not drop the battery or expose to strong shocks or vibrations.
- Always store the battery in a cool, dry place.
- Do not use the battery if damaged.

Transmitter Overview

Front View








Rear View



Screen Overview

Power On

- Make sure that all switches are at their highest position and the throttle is at its lowest position.
- Hold down the two power buttons on each side of the screen until the status indicator lights up.
- Connect the bind cable to the B/VCC port on the receiver.



Power Off

- Disconnect the receiver from power. The system will not power off if the receiver is still connected.
- Hold down the power buttons on each side of the screen.



Make sure to disconnect the receiver's power before turning off the transmitter. If the receiver is still on, the system will prompt "For your safety, please turn off the receiver first.". If you turn off the transmitter forcefully, it may lead to unintended operation and cause an accident.

Specifications

Channels	8
Model Type	Fixed-Wing/Glider/Helicopter
RF Range	2.408-2.475GHz
RF Power	<20 dBm
RF Channel	135
Bandwidth	500kHz
Modulation Type	AFHDS 2A/AFHDS 2/AFHDS
Exponential Function Enabled	
Throttle Trim	
Airplane/Helicopter Structure	
Rudder Trim	
Weight	720g
Display	WQGA 3.55inch Touch Resistive TFT Color Screen , 262K 240*160 pixels
Size	190*95*255mm
On-Line Update	Yes
Color	Black
Certificate	CE0678, FCC ID:N4ZFLYSKYI8

Model Setup

If you are flying an airplane or glider:

- Touch the plane picture on the main screen and then select [Modify...] in the [Airplane structure] screen.
- Select the control surfaces that your model has.
- Select [Back] to exit the menu.

These are located on the bar at the bottom of the LCD.



Back button: Use this icon to return to a previous menu or exit a function.



Default button: This icon resets the current page to its default parameters.



Assign Switch: Some functions require, or are assignable to a hardware switch (SWA ~ SWH) or knob (VRA ~ VRC).



Enable/Disable: These icons enable and disable the current function. When the tick icon is visible the function is active.

If you are flying a helicopter:

- Select [Setup], swip left to right on the screen and then select [Models].
- Select [Set model type], and then [Helicopter]. Select [Yes] to confirm. Then the [Helicopter structure] screen displays.
- Select the configurations that your model has and then select [Back] to exit the menu.

Basic Operations

Install the Battery

- Remove the battery compartment cover.
- Insert the battery making sure the contacts on the battery, and in the system are properly aligned.
- Replace the battery compartment cover.