

Jan-28-2017

FLYSKY TRANSMITTER & RECEIVER COMPATIBILITY TABLE

2.4011.05				non-AFHDS AFHDS								R E C E I V E R									
_,																	AFHDS 2A				
	Туре	No. of channels		3-ch	6-ch	3-ch				6-ch	8-ch	4-ch	3-ch	4-ch	6-ch			8-ch	10-ch		
			Tx / Rx	GR3A	R6A	GR3B	GR3C	GR3E	GR3F	R6B	R9B	iR4	A3	iA4B	A6	iA6	iA6B	X6B	A8S	iA10	iA10
AFHDS 2	wheel	2-ch	GT2	Х	Х	٧	٧	٧	٧	V	٧	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
			GT2B	Х	Х	√	٧	٧	٧	٧	√	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
		3-ch	GT3	1)	1)	2)	2)	2)	2)	2)	2)	Х	Х	Х	X	X	Х	Х	Х	Х	Χ
			GT3B	Х	Х	٧	٧	٧	√	3)	3)	Х	X	X	X	X	Х	Х	Х	Х	Х
			GT3C	Х	Х	٧	٧	٧	٧	3)	3)	X	X	X	Х	Х	X	X	X	X	Х
	stick	2-ch	T2A	Х	Х	√	٧	٧	√	√	V	Х	Х	Х	Х	X	Х	Х	Х	X	X
		4-ch	T4A	√	√	Х	Х	Х	Х	Х	Х	X	X	X	Х	X	X	X	X	X)
			T4B	X	X	٧	٧	٧	√	√	٧	X	X	X	Х	X	X	X	X	X)
		6-ch 8-ch	CT6A	√	√	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	,
			СТ6В Т6	X	X	V	V	٧	V	٧	√ √	X	X	X	X	X		X	X	X	
			TH9X	1)	X 1)	2)	2)	√ 2)	2)	√ 2)	2)	X	X	X	X	X	X	X	X	X)
	wheel	4-ch	iT4	X	1) X	4)	4)	4)	4)	4)	4)	٧	X	X	X	X	X	X	X	X	,
AFHDS 2A	wheel	2-ch	GT2E	X	X	٧	<i>→</i>)	→)) √	-+) √	X	∧	∧	∧	∧	√	?	?	∧	,
			GT2G	X	X	٠ ٧	٧	v √	۷ ۷	V	٧	X	V	V	<u>۷</u>	V	٧	?	?	V	,
			GT2G	X	X	٠ ٧	٧	∨	٧	٧	٧	X	V	V	∨	V	٧	?	?	V	,
		3-ch	RED i3	X	X	v	٧	V	V	٧	٠ ٧	Х	<u>√</u>	V	V	V	٧	,	?	٧	,
		4-ch	iT4S	X	X	٠ ٧	√	V	<u>۷</u>	٧	ا	<i>X</i>	<u>√</u>	√	V	<u>۷</u>	<u>۷</u>	?	?	٧	,
	stick		i4	X	X	٧	٧	V	V	٧	٧	Х	V	٧	٠ ٧	٠ ٧	٧	· √	· √	٧	,
		4-ch	i4X	X	X	٧	٧	V	٧	٧	٧	Х	٧	٧	√ √	٧	٧	٠ ٧	٧	V	,
		6-ch	i6	X	Х	٧	٧	V	٧	٧	3)	Х	٧	٧	V	٧	٧	٧	3)	3)	3
		10-ch	i6X	X	X	٧	٧	V	٠ ٧	٠ ٧	٧	Х	٧	٧	٧	٠ ٧	٧	٠ ٧	٧	٠ <u>/</u>	,
			i6S	X	Х	Х	Х	Х	Х	Х	Х	Х	٧	٧	٧	٧	٧	٧	٧	٧	١
			i10	X	Х	٧	٧	٧	٧	٧	٧	٧	٧	٧	٧	٧	٧	٧	٧	٧	1
					compatib			only with													

only with FS-TM002 RF module

all channels available with transmitter firmware hack

only later version with upgraded firmware

X not compatible

? not confirmed













AFHDS AUTOMATIC FREQUENCY HOPPING DIGITAL SYSTEM